SPECIFICATIONS

Satellite Signals Tracked Simultaned	busly
Signal tracking	600 channels
	BDS B1,B2,B3
	GPS L1C/A,L1C,L2C,L2E,L2P,L5
	GLONASS L1C/A,L1P,L2C/A,L2P,L3
	QZSS L1C/A,L1 SAIF, L1C,L2C,L5,LEX
	SBAS L1C/A,L5
	Galileo Glove-A and Glove-B, E1, E5A, E5B, E5AltBOC, E6
	MSS L-Band: Preserved
GNSS features	Positioning output rate: 1Hz~50Hz
	Initialization time: <10s
	Initialization reliability: >99.99%
Positioning precision	
Code differential GNSS positioning	Horizontal: ±0.25m+1ppm Vertical: ±0.50m+1ppm
SBAS positioning	Typically<0.5m 3DRMS
High-Precision Static	Horizontal: ±3mm+0.1ppm Vertical: ±3.5mm+0.4ppm
Static and Fast Static	Horizontal: ±2.5mm+0.5ppm Vertical: ±5mm+0.5ppm
UHF RTK	Horizontal: ±8mm+1ppm Vertical: ±15mm+1ppm
Network RTK	Horizontal: ±8mm+0.5ppm Vertical: ±15mm+0.5ppm
RTK initialization time	2~8s
User interaction	
Operating System Buttons	Linux
Indicators	Double Button Operation
Web UI	Four Indicator Lights
	Freely configure and monitor the receiver by accessing to the web server via Wi-Fi or USB
Voice guide	iVoice intelligent voice technology provides status and voice guide
Secondary development	Supporting Chinese, English, Korean, Russian, Portuguese, Spanish, Turkish and user defined language
Secondary development Hardware performance	Providing secondary development kit
Dimension	120mm/Diamatar/v95_2mm/Llaight)
Weight	130mm(Diameter)x85.3mm(Height)
Material	820g
Operating	Magnesium aluminum alloy shell
Storage	-45°C~+70°C
Humidity	-55°C~+85°C
Waterproof	100% Non-condensing
Dustproof	IP67 standard, protected from short time immersion to depth of 1m IP67 standard, fully protected against blowing dust
Shock and vibration	Withstand 2 meters pole drop onto the cement ground naturally
Battery	6800mAh, Li-ion battery built in, 7.4V
Battery life	10-14hours (Supporting external battery)
External DC Power	9-28V
Communications	3200
I/O port	5PIN LEMO external power port+RS232, 7PIN external USB(OTG)+Ethernet
	1 radio antenna interface
Wireless modem	Built-in radio 1/2/3W
Frequency Range	410-470MHz
Communication Protocol	TrimTalk450s, TrimMark3, SOUTH (KOLIDA)
Double Module Bluetooth	BLEBluetooth 4.0 standard, support for android, ios cellphone connection
	Bluetooth 2.1+EDR standard, able to transmit and receive RTK correction data in Base-Rover mode.
NFC Communication	Realizing close range (shorter than 10cm) automatic pair between receiver and controller
	(controller equipped NFC wireless communication module needed)
External Devices	Optional external GPRS/EDGE dual-mode communication module, switchable;
	allow to connect external WLAN card
WIFI	
Standard	802.11 b/g standard
WIFI Hotspot	The WIFI hotspot allows smart mobile terminal to connect and access to the internal webserver to control
	and monitor receiver
WIFI data link	To work as the datalink that receiver is able to broadcast and receive differential data via WIFI
Data storage/ Transmission	
Data Storage	8GB SSD internal storage
	Support external USB storage (up to 32 GB) and automatical cycle storage
	Changeable record interval, up to 50Hz raw data collection
Data Transmission	USB data transmission, supporting FTP/HTTP data download
Data Format	Differential data format: CMR+, CMRx, RTCM 2.1, RTCM 2.3, RTCM 3.0, RTCM 3.1, RTCM 3.2
	GPS output data format: NMEA 0183, PJK plane coordinates, Binary code, Trimble GSOF
	Network model support: VRS, FKP, MAC, fully support NTRIP protocol
Inertial sensing system	
Electronic bubble	Controller software displays electronic bubble, user can check leveling status of the centering rod real time
Thermometer	Built-in thermomter sensors, features intelligent temperature control technology which can monitor and
	adjust the temperature of receiver in real time







GUANGDONG KOLIDA INSTRUMENT CO., LTD.

Add: 7/F, South Geo-information Industrial Park, No.39 Si Cheng Road, Tian He IBD, Guangzhou 510663, China Tel: +86-20-22139033 Fax: +86-20-22139032 Email: export@kolidainstrument.com market@kolidainstrument.com http://www.kolidainstrument.com

SuperRTK K3

600 Channels, Smallest Full Function RTK Ever Enhanced BEIDOU Signal Processing Ability 14 Hours Continuous Working Web UI, Wifi, E-Bubble

600 Channels Full constellations

K3 is equipped with a Kolida K800 series GNSS board which has 600 channels and is capable to support multiple satellite constellations: GPS. GLONASS, BEIDOU and GALILEO, SBAS, including the latest Beidou-3 system.

(The receiver has the ability to get RTK FIXED solution by using individually any of the existed satellite systems and not necessarily primarily use GPS system.)



Small As an Apple


The diameter of the K3 is only 13cm, height only 8.53cm, and the weight is only 820g. It is as small as an apple that you can even put it into your pocket.

New Integration Technology New Level of Stability

GNSS antenna, Bluetooth, wifi module are integrated into one board, which helps to save the internal space of K3, making the signal better and performance more stable.

This design also can reduce multipath effect, help receiver to keep fixed solution under canopy and even work closely to buildings.

The Smallest UHF Radio in the History



The latest micro UHF module has high sensitivity and low power consumption.

Magnesium Aluminum Alloy Shell Is Shatter Resistant

K3 is able to withstand 2 meters pole drop onto the cement ground naturally and fully protected against blowing dust.






Energized Battery Increased Working Time

4 hours quick charge is enough to enable K3 a 14 hours of using time.

Other Features



New Case, More Portable



The light weighted case for K3 is stable and wear resistant.

Data Collector. Simply Trustable

T17N

- Windows Mobile 6.5
- 1Ghz CPU, RAM 512MB
- 1GB ROM, Extendable to 32GB
- 3.7V. 6500mAh removable Li-ion
- 3.7 Inch, 480X640VGA
- WCDMA
- Include EGSTAR3.0

New app. New Productivity

SurvX Android

Windows CE data controller is too old technology? No problem. Simply download SurvX App on your smart phone or tablet. Enjoy the smooth operation of Android platform !



Seamless Connection •NFC Saving-Time Bluetoot Auto Connection

Rich & Practical Progr CAD function & Line w •3D display mode

•Road & Power line pro

Post-processing SW. Free of Charge

KOLIDA GEO Office Integrates static data processing and kinematic data adjustment







H3PLUS

- Android 6.0
- Quad-core 1.3GHz CPU, 2GB RAM
- 4.3 Inches, WVGA 800X480dpi
- 8 megapixel camera with auto focus
- 6500mAh, up to 10Hours
- Dual SIM Card
- 4G FDD TDD network, 3G WCDMA
- GPS\GLONASS\SBAS\A-GPS
- Include EGSTAR

I	Intuitive interactive design Reducing mistakenly touching
th Search	•User define program menu
	 Signal strength graphic display
rams	Creativity
work	•Saving & Sharing coordinate system by QR code •Data recovery & Encryption function
ogram	•Support Google map and other base map

Intelligent

- •Antenna manager with popular receiver types.
- Fast processing and clear display
- •Manually edit and filter satellite data for best result
- Update online.

Versatile

- Compatible with numerous data format.
- •Export abundant types of report.
- Transformable to RINEX format