

SPECIFICATIONS

KTS-442UT	
Measuring Range	
1P	5.0km
3P	8-10 km
Non prism	1000m (1500m optional)
Digital Display	Maximum: 99999999.9999m Minimum: 0.1mm
Accuracy	With prism & Reflective Sheet 60x60mm: 2mm+2ppm, without prism 3mm+2ppm
Measuring Time	Tracking 0.1s, Fine 0.3s (Prism in Optimal Condition), 0.3s to 3s (Non-prism in Optimal)
Atmospheric Correction	Automatic Correction by Inputting Parameter
Prism Constant	Automatic Correction by Inputting Parameter
Angle Measurement	
Measurement Method	Absolute Encoding
Diameter of The Raster Disk	79mm
Minimum Reading	1 " / 5 " Optional
Accuracy	2 "
Detection Method	Horizontal: Four Sensors Vertical: Four Sensors
Telescope	
Image	Erect
Length	154mm
Effective Aperture	45mm (DTM 50mm)
Magnification	30 X
Field of View	1° 30'
Resolving Power	3 "
Minimum Focus	1m
Compensation	
System	Dual axis liquid-electric
Working Range	±3'
Resolving Power	1 "
Sensitivity of Vials	
Plate Vial	30 " /2mm
Circular Vial	8' /2mm
Laser Plummet	Brightness Level in 5 stages adjustable
Data Storage and Communication	
Internal Memory	12MB (up to 100,000 points)
External Memory	USB Flash Disk (up to 256 GB)
Communication Port	USB, Bluetooth. Data Input: CSV. Data Output: DAT,CSV, DXF
Display	
Type	Dual sides, 6 lines, black and white Display. Alphanumeric keyboard, 24 keys with Backlight
Battery	
Power Supply	Rechargeable battery (3100mAH) x 2 units
Voltage	7.4V DC
Operation Time	20 hours by two batteries
Dimension and Weight	
Dimension	160mm×150mm×330mm
Weight	5.7 kg
Environmental Specification	
Dust/Water (IEC60529)	IP66
Temperature Range	Operating: -30℃~60℃. Storage: -30℃~70℃
Humidity	95%, non-condensing

KTS-442UT

The High Performance
Total Station with Great
Reliability, Flexibility and Economy



Kolida's Vision and Mission:

Delivering more values to global users by providing sustaining innovation and uncompromising quality



Welcome to Kolida Instrument, a fusion of passionate people, continuously innovated technology, services, as well as 25 years experience of manufacturing total station.

Every year more than 12,000 customers choose to purchase Kolida total stations. To ensure our instruments meet the high precision and quality requirement of global users, we manufacture them in state-of-the-art facilities around China.

We recognize certain employees as Master Craftspersons, exceptionally skilled people who take charge of manufacturing the parts of products that require extremely high precision and quality. Their Fast, accurate work creates uniform products of superb quality.













In addition to introducing the latest manufacturing facilities and technologies, we are shortening manufacturing lead times and reducing costs by reviewing production processes and innovating Procurement, to offer you a good instrument as affordable as possible.

You demand, our mission.










Seven Major Improvements

To lift your capability and productivity

TECHNOLOGIES

- | | | |
|---|---|--|
| 
1500m
1000/1500m
Reflectless | 
Speed
Ultra Fast
Measurement | 
Co-axial
Laser Beam |
| 
Ultra Low-
noise Amplifier | 
Noise Phase
Analysis | 
Carrier
Frequency |
| 
Bluetooth | 
USB Flash
Memory | 
Dual Axis
Compensation |
| 
Laser Plummet | 
Laser Pointing | 
IP66 |

PROGRAMS


- | | | |
|--|---|--|
| 
REM | 
Resection | 
Road Design |
| 
Column Offset | 
Plane Offset | 
Distance Offset |
| 
Area Cal. | 
MLM | 
P/L SO |

Video and Article: <http://www.kolidainstrument.com/product/details/id/81.html>



Total Station Module of Ksurvey App: Four Main Features to Give You More Power & Freedom


CAD Stakeout: Increasing Productivity & Decreasing Error



CAD Stakeout allows you to import **CAD basemap** and stakeout it, without inputting point coordinates one by one.

When you need, you also can connect to your local **online map** and overlap it to CAD basemap, to increase the precision of your job.


Point Survey & Stakeout: More Ease and Convenience



With graphic display, now it is easy to you to observe the relation between occupied point and target points. It will help you to make less mistakes when measuring many points.

The stakeout program screen displays information more completely, indicates target points more intuitively, your workflow will be smoother than before.


Line Stakeout: Smarter than Traditional Way



User is allowed to manually choose points from library, line will be formed by program automatically. Then user input interval distance, setout points will be calculated out and displayed on screen.

This function is suitable for road or other objective that is containing lines.


Measure & Draw: Save Time in Both Field work and Indoor Work



User is allowed to draw line, polygon, circle...up to 11 kinds of graphic, while measuring target points. No need to manually draw draft map anymore.

User is allowed to manage different objectives as different layers. The draft map can be saved and output in CAD format, and to be used in indoor works.

Other Features: More Innovation, No Limitation



Download & Share
(.csv, .dxf, .txt, .xls)

Resection

Set Occupied Point from CAD basemap or Graphic Map

Other Modules of Ksurvey App: GNSS, Marine Survey, 3D Laser Scanner...